

FITTING INSTRUCTIONS FOR COMPUTER COVER

FORD BA – FG 6cyl & V8 & FORD Territory

Part # CPC001

Kit Includes

1x Computer Cover

3x Stainless Steel Allen Key Bolts

Tools Required

Hacksaw Blade

Bladed Screwdriver

4mm Allen Key

1. Using a hacksaw blade, cut a slot in the top of each rivet head on the computer housing; this needs to be just enough to get a bladed screwdriver in to turn.
2. Using a bladed screwdriver, unscrew each rivet (anti-clockwise) and discard.
3. Fit cover supplied over computer housing.
4. With the 4mm Allen key, affix cover in place using the 3x Allen key bolts supplied. Spray CRC to threads before screwing.

NB: Some models may have a switch attached to the computer mounting bracket – either remove and tuck in under computer cover or mark and cut computer cover accordingly.

□ ENJOY THE DIFFERENCE □

Another Quality Product From SS Inductions

...making good cars better!

© SSI 2003