

FITTING INSTRUCTIONS FOR NON-SUPERCHARGED ENGINE COVERS

HOLDEN VE V8

Part # SCC002

Kit Includes

2x Engine Covers with High Temp Heat Shield

3x Alloy Brackets with Speed Clips

4x 6mm s/s Allen Key Bolts

4x s/s Washers

3x s/s Button Head Bolts

3x Alloy Spacers

9x Spacing Washers

Tools Required

10mm Socket

Allen Key Set

1. Remove the original engine cover.

Fit RH side (driver side) cover:

2. The RH side bracket has cut outs to clear the coil plugs. Remove the first 3 x top 10mm bolts that hold the first 3 coils in place and retain. Place bracket supplied over holes and using 3 of the 9x spacing washers supplied per retained bolt secure bracket. Note that these spacing washers fit to the underneath of the bracket supplied. Remove oil filler cap, place RH cover supplied onto bracket, ensuring heater hoses are not restricted in any way. Secure cover using 2 of 4x 6mm Allen key bolts and 2 of 4x s/s washers supplied. Reattach oil filler cap.

Fit LH side (passenger side) cover:

3. Remove the second, third and fourth 3 x top 10mm bolts that hold the second, third and fourth coils in place (ie missing the first coil). Discard bolts. Place brackets supplied over holes (with the shorter bracket to the rear) and using 1 of the 3x s/s button head bolts and 1 of the 3x alloy spacers supplied per bolt secure bracket. Note that these alloy spacers fit to the underneath of the bracket supplied. Place LH cover supplied over bracket and secure using the remaining 2 of 4x 6mm Allen key bolts and 2 of 4x s/s washers supplied.