

FITTING INSTRUCTIONS FOR GROWLER® COLD AIR INDUCTION UNIT

HOLDEN VT-VY V6 & V6 Supercharged

Part # CAI031

Kit Includes

1x Airbox Assembly
(incl. box, lid & rewashable filter)
3x Black Self-Tapping Screws
1x Metal Retaining Clip

Tools Required

Drill
Phillips Screwdriver
8mm Socket

1. Remove the airflow meter. Remove the rubber sleeve and clamp from standard airbox and retain.
2. Remove factory intake.
3. Remove standard airbox by gently pulling up from its rubber mounts. Remove temp sensor from the lid of standard airbox and refit to pre-drilled hole in Growler® airbox, using metal retaining clip supplied.
4. Disconnect rubber overflow tube from below radiator cap.
5. Fit Growler® airbox by sliding radiator overflow bottle through hole in Growler® airbox. Reconnect rubber overflow tube then position Growler® airbox under radiator support bracket.
6. Drill 3 holes in radiator support bracket & secure Growler® airbox using the 3 x black self-tapping screws supplied.
7. Refit rubber sleeve and clamp to lid of Growler® airbox. Refit airflow meter ensuring directional arrow is pointing toward motor.

Don't forget to keep the rewashable Big Mouth® Filter clean!

Please note that the engine computer in your vehicle may take up to several hundred kilometres to adjust to the increased airflow and produce the maximum effect.

□ ENJOY THE DIFFERENCE □

A Growler® Product From SS Inductions
...making good cars better!

© SSI 2008/Regd Design