

# **FITTING INSTRUCTIONS FOR INTAKE 'Y' PIPE** **(Connecting Throttle Body To Airflow Meter)**

## **HOLDEN VE V8**

### **Part # ITP002**

#### Kit Includes

1x Intake 'Y' Pipe  
(with 2 x hose clamps attached)  
1x Vacuum Line  
1x Spacer (for maf-less use only)

#### Tools Required

7mm socket  
8mm socket  
(or Flat-Bladed Screwdriver)

1. Using a 7mm socket, loosen the hose clamps at each end of the standard intake pipe. Remove pipe from the throttle body and airflow meter, disconnecting & discarding vacuum line, retaining clamp from airflow meter (lift up engine cover for access).
2. Lubricate (eg WD40) throttle body end of Y Pipe for ease of fitting. Attach Y Pipe. Fit hose clamp retained in Step 1 to flexible rubber boot and reattach to airflow meter. Fit vacuum line supplied to motor and Y Pipe.
3. Tension hose clamps.

#### For maf-less application:

Use spacer supplied in place of airflow meter.

☐ ENJOY THE DIFFERENCE ☐

A Big Mouth Product From SS Inductions

*...making good cars better!*

© SSI 2008/Regd Design