

OTR GROWLER® COLD AIR INDUCTION

NB: THIS PRODUCT REQUIRES A MAF-LESS TUNE AND SHOULD NOT BE RUN WITHOUT ONE.

FITTING INSTRUCTIONS FOR OTR GROWLER® COLD AIR INDUCTION UNIT

HOLDEN VE V8

Part # OTR001

Kit Includes

1 x Housing, top & bottom sections
1 x Y-Pipe
2 x Pod Filters
1 x Vacuum Line
3 x Scrivets
1 x Rubber Grommet
1 x Temperature Sensor & Extension Loom

Tools Required

7mm Socket
8mm Socket
10mm Socket
Phillips screwdriver

Remove factory panel (if applicable)

1. Remove factory intake from airflow meter to throttle body. Remove vacuum line & discard.
2. Remove airbox.
3. Unclip housing as supplied to separate top & bottom sections and remove Y-Pipe and filters.
4. Using the bottom section, place round throttle body and secure front using 3 x scrivets provided.
5. Fit Y-Pipe & filters supplied to throttle body, ensuring the foam on bottom housing is not caught up. Ensure the vacuum port under Y-Pipe is through the hole in the bottom housing. Tension hose clamp.
6. Fit the top housing and secure to bottom section with the 4 x clips attached.
7. Using the vacuum line supplied, fit the small end to the motor (where existing vacuum hose was) and the large end to the vacuum port on the Y-Pipe where it protrudes through the bottom housing.
8. Remove the rubber strip from underneath the bonnet.

NB: The temperature sensor fits into the hole with the attached rubber grommet on the side of the bottom section of the housing.

Don't forget to keep the rewashable pod filters clean!

An OTR Growler® Product from SS Inductions
...designed for track use only!

© SSI 2008/ Regd Design

*SS Inductions Pty Ltd is not responsible for the legality or otherwise of this product. Check with your State's Road traffic Authority regarding rules & regulations on relevant modifications to your vehicle and use a qualified mechanical engineer/tuner for fitment.