FITTING INSTRUCTIONS FOR INFILL PANEL

HOLDEN VY & VZ SS UTE
Part # VUP002

Kit Includes
1x Plastic Infill Panel
7x Short Self-Tapping Screws
2x Brackets

Tools Required
Phillips Screwdriver
Drill

1. Remove rear number plate.

2. Remove centre number plate light, pulling wires through as far as possible. Disconnect bulb from light socket.

3. The brackets provided are connected to the bottom of the panel to attach it to the vehicle. Ensure each bracket is evenly spaced, approx. 12cm from either end (note that this is a guide only – adjust to suit your vehicle). Position panel, lining up to match existing lines on rear bumperettes, noting that slight adjustment of bumperettes may be necessary once infill panel is completely fitted.

4. Establish and mark where you will be attaching the 2 brackets; remove panel, drill holes in the panel and in the vehicle where marked. Secure brackets to the panel with 2 of the self-tapping screws provided.

5. To secure the top of the panel to the vehicle, drill a hole in the panel and in the vehicle approx. 21cm to the left of the middle of the spare wheel release cutout.

6. Reposition panel to vehicle; secure bottom brackets with 2 of the self-tapping screws provided. Secure top with 1 of the self-tapping screws provided, ensuring number plate light wiring is accessible to refit light.

7. Refit number plate light and reconnect bulb.

8. Refit number plate, using the last 2 self-tapping screws provided.

□ ENJOY THE DIFFERENCE □

Another Quality Product From SS Inductions
…making good cars better!
© SSI 2003