FITTING INSTRUCTIONS FOR THROTTLE BODY SPACER

FORD BA – BF V8 RANGE (V8, XR8, GT & GTP) & FG XR8
Part # TBS001

Kit Includes	*Tools Required*
1x Throttle Body Spacer	*5mm Allen key*
4 x Allen key bolts	*Phillips Screwdriver*
1 x Rubber Seal	*8mm Socket*

1. Disconnect intake pipe from airbox to throttle body.
2. Remove standard throttle body using 8mm socket. Discard 4 x original bolts.
3. Leaving original gasket in place, fit spacer ensuring that the rubber seal is facing throttle body.
4. Refit throttle body using the 4 x Allen key bolts supplied.
5. Tension Allen key bolts evenly.
6. Reconnect intake pipe.

NOTE THAT THE COMPUTER IN YOUR VEHICLE WILL TAKE SEVERAL HUNDRED KLMS TO FULLY ADJUST TO THE INCREASED AIRFLOW.

□ ENJOY THE DIFFERENCE □

A Big Mouth Product From SS Inductions
…making good cars better!
© SSI 2006/Regd Design